

Detect errors in screw fastening in real time with high accuracy by counting the pulse of the motor. No need to rely on the experience or logic of operators any longer. The screwdriver itself will enhance the quality of screw fastening. Brushless® Screwdriver

Built-in Screw Counter / Pulse Counter

BLG-BC2 Series

New variations of BLG-BC2 Series are released.

BLG-BC2 has multiple functions such as direct teaching, screw counter, ultra-precise detection of screw fastening error and output of work data. It has incorporated many of the most advanced technologies from HIOS.



Advantages of BLG-BC2

Direct teaching allows a simple setting

By installing several fasteners into the assembly the driver learns the number of motor revolutions required to correctly tighten the fasteners to the desired torque. The driver then establishes the minimum to maximum revolutions for process acceptance.

Drastically increases the error detection rate

Screws that were once difficult to judge visually, (misplaced screws of different type or length, recessed screws or floating screws due to seized cables) are now detected.

Display panel indicates the measured values

The user can check the measured values on their display panel, enhancing the user's quality of performance at work.

Installed serial port (RS-232C) makes it possible to set the driver by remote control and record pulse values of each screw tightening for traceability.

Data transmission and reception are enabled by connecting with external devices, including PC and PLC.

Screwdriver specifications

New model

BLG-4000BC2-LT



New model

BLG-7000BC2







| Start Type Model | | Output Torque Range N•m Ibf•in (Kgf •cm) | Torque Switchi ng | Unloaded Rotation Speed (rpm) ±10% | | | erna l ons(mm) | | Power Supply | | Bit type (selectable) (Refer to P3.) | | |
|--------------------------------------|---------------------------------|--|----------------------------|--|---------------------------------|--|--------------------------|---------------|--------------|--------|--------------------------------------|---|---------------------|
| | | | | | Machine Screw/ Tapping Screw | Grip (mm) | Length (mm) | Weight (g) | T-45BL | T-70BL | A HIOS Shank H4 | B Two-way Shank type H5 / 5HEX | HEX Shank 1/4HEX |
| Lever start | Low torque type BLG-4000BC2-LT | 0.03-0.2 0.3-1.7 (0.3-2) | Stepless adjustm ent | 1,000/ 690 | 1.0-2.3/ 102.0 | φ32.7 | 207 | 312 | • | • | • (1) | _ | _ |
| | BLG-4000BC2 | 0.1-0.55 0.9-4.8 (1-5.5) | | 1,000/ 690 | 1.4-2.6/ 1.4-2.3 | | 206 | 370 | • | • | • (2) | - | • |
| Lever and Push-to start (two-way) | BLG-5000BC2 | 0.2-1.2 1.7-10 (2-12) | | 1,000/ 690 | 2.0-3.0/ 2.0-3.0 | WD cut shape MAX: φ38 - Min: φ32 | 235 | 425 | • | • | • (3) | • | • |
| | High speed type BLG-5000BC2-15 | 0.3-1.0 2.6-10 (3-10) | | 1,500/ 1,000 | 2.3-3.0/ 2.0-2.6 | | 235 | 425 | • * | • * | • (3) | • | • |
| | High speed type BLG-5000BC2-18 | 0.5-1.5 4.3-13 (5-15) | | 1,800/ 1,200 | 2.3-3.0 2.0-2.6 | | 235 | 425 | _ | • * | _ | • | • |
| | High torque type BLG-5000BC2-HT | 0.5-2.0 4.3-17 (5-20) | | 730/ - | 2.0-4.0 2.0-3.0 | | 235 | 425 | • * | • * | _ | • | • |
| | High torque type BLG-7000BC2 | 0.7-2.8 6.1-30 (7-28) | | 1,200/ 800 | 2.6-5.0 2.6-4.0 | WD cut shape MAX: φ40 Min: φ37 | 238 | 670 | _ | • * | _ | • | • |

Use only 2(HI) power outlet with the *models. These models may not perform properly on 1(LOW) power outlet.

◆ For BLG-4000BC2 Series, two types of torque adjustment spring are available: one for high torque (mounted on the body) and one for low torque (as an accessory). Please switch the springs according to the type of task.


Accessories


- Adjustment spring for low torque (only for 4000 Series)
- Driver Code 2m(6P)
- HEX L-wrench: one (flat-to-flat 5mm) (only for 5000/7000 Series)
- Bits: one each for each type (only available with HIOS shanks)
- **A** (1) H4 $\left| +\#0(\varphi 2.0 \times 40 \text{mm}) + \#0(\varphi 2.5 \times 40 \text{mm}) \right|$
- (2) H4 $+#0(\varphi 2.5 \times 40 \text{mm}) +#1(\varphi 4.0 \times 40 \text{mm})$
- (3) H4 $\left| \begin{array}{l} +#1(\varphi 4.0 \times 40 \text{mm}) \\ +#2(\varphi 4.0 \times 40 \text{mm}) \end{array} \right|$


B H5 $\left| \begin{array}{l} +#1(\varphi 5.0 \times 60 \text{mm}) \\ +#2(\varphi 5.0 \times 60 \text{mm}) \end{array} \right|$


Please purchase commercially available one.

Output torque guide (HI input)












Torque scale







Detectable Errors

Including mixing of screws (different type or length), screw floating in a deep hole that is difficult to detect visually and seizing of a wiring cable.



Related Products





Power Supply

| Number of connectable screwdrivers | 1 unit | | | | | |
|------------------------------------|--------|--------|--|--|--|--|
| Power supply Screwdriver | T-45BL | T-70BL | | | | |
| BLG-4000BC2-LT | • | • | | | | |
| BLG-4000BC2 | • | • | | | | |
| BLG-5000BC2 | • | • | | | | |
| BLG-5000BC2-15 | • * | • * | | | | |
| BLG-5000BC2-18 | _ | • * | | | | |
| BLG-5000BC2-HT | • * | • * | | | | |
| BLG-7000BC2 | _ | • * | | | | |

(Note) Use only 2(HI) power outlet with the *models. These models may not perform properly on 1(LOW) power outlet.

■Plug type

(AC220-240V)








Please select a bit drive when you purchase a screwdriver.

There are three drive types: HIOS shank, two-way shank and Hex shank.

Please make sure to specify the shank.




Product videos

Videos to explain how to use BC2, etc., are available on our website. Please check them.

https://hios.com/EN/movie/

| Main functions | Examples of error detections | Direct teaching | | |
|----------------|------------------------------|-----------------|--|--|
| | | | | |



HIOS Inc.

Head Office: 1-35-1 Oshiage, Sumida-ku, Tokyo 131-0045 Japan Phone: +81 (Japan) 3-6661-8821

Osaka Office: 18F Naniwasuji SIA Bldg., 2-4-2 Shinmachi, Nishi-ku, Osaka City, Japan 550-0013 Phone: +81 (Japan) 6-6533-0903

Nagoya Office: 9F Kirix Marunouchi Bldg., 1-17-19 Marunouchi, Naka-ku, Nagoya, Aichi Pref., Japan 460-0002 Phone: +81 (Japan) 52-219-5566

Yamagata Factory: 5 Takagi, Yamagata City, Yamagata Pref., Japan 990-2346 Phone: +81 (Japan) 23-645-8100





Headquarters/Yamagata Factory

/ Headquarters/Yamagata Facto